

AUTO PROTECTION PLANS

GOLD COVERAGE

All Parts listed under Powertrain and Silver, plus:

SUSPENSION

- control arms • control arm shafts • control arm bushings • radius arms and bushing • torsion bars • coil and leaf springs • wheel beanogs
- stabilizer bar • stabilizer links • stabilizer bushing • spindles
- steering knuckles • ball joints • bearings and bushings

BRAKES

- brake caliper actuators • master cylinder • vacuum assist brake booster • disc brake calipers • wheel cylinders • brake springs, clips, and retainers • vacuum brake booster pump • compensating valve
- linkage and cables • self-adjusters • brake hydraulic lines and fittings

COOLING & HEATING

- electric cooling fan motor • blade assembly • fan clutch
- radiator (ONE RADIATOR PER LIFE OF CONTRACT)

ELECTRONICS

- electronic level control system • ignition module • knock control sensors and controller • driver information display and module • keyless entry system • manufacturer-installed theft deterrent devices/systems
- the following parts of the ABS: electronic wheel sensors

SEALS & GASKETS

- seals and gaskets for covered parts except seals and gaskets for minor loss of fluid or seepage

AUTOMOTIVE PROTECTION PLAN LIMITS & EXCLUSIONS

Coverage is subject to deductibles, limits and exclusions. The contract covers repairs only of covered parts and only when they suffer a breakdown as defined in the contract. Under some circumstances, a breakdown of a covered part may not be covered (for example, failure due to misuse or lack of proper maintenance or when a non-covered part is what caused the covered part to fail). Also, the exclusions contain a list of parts not covered, some of which may be associated with a covered part (for example, brake drums, pads and rotors; exhaust pipes, mufflers and catalytic converters; and body and trim items). Please see the service contract for details.

ADDITIONAL PLAN BENEFITS

Emergency Roadside Assistance

- Towing or winch-out service (up to \$150 per occurrence)
- Flat tire replacement
- Delivery of fuel, water and other fluids (excluding the cost of fluids)
- Lock-out assistance
- Jump start

Substitute Transportation

Benefits include defined rental car reimbursement. Also, coverage for Uber or Lyft services, up to \$50 per day. (See contract for additional details.)

PLATINUM COVERAGE


Exclusionary coverage providing protection for more than 15,000 parts!

This marketing material is provided for review purposes only.

See contract for complete coverage details, benefited items, conditions and exclusions.

This insert includes AI-generated imagery.

AVERAGE REPAIR COSTS*



833-357-2366 • 434-384-1150 • info@dkpadmin.com
4925 Boonsboro Road, Suite 238, Lynchburg, VA 24503

DKPADMIN.COM

AUTO PROTECTION PLANS



ALL FOUR PLANS INCLUDE ROADSIDE ASSISTANCE AND RENTAL

POWERTRAIN COVERAGE

GASOLINE/DIESEL ENGINE

- valve cover(s) • timing cover • crankshaft • cylinder head(s)
- engine block • pistons-pins and rings • connecting rods
- camshaft and followers • internal bearings • serpentine belt
- oil pump • water pump • engine torque strut • harmonic balancer
- engine mounts • drivebelt pulleys • dipstick and tube • oil pan
- valve springs • valve seats • valve guides • lifters • eccentric shaft
- push rods • timing belt/chain • timing gear • tensioners and retainers
- valves • intake and exhaust manifolds • manufacturer-installed turbocharger(s) • manufacturer-installed supercharger
- rocker arms/shafts and bushings

TRANSMISSION

- (Automatic, Continuous Variable (CVT) Standard & Transfer Case)
- all internal lubricated parts contained within the cases: transmission/transfer case/torque converter • filler tube and dipstick
 - internal linkage • flywheel/flexplate • vacuum modulator

DRIVE AXLE

- (Front/Rear/ AWD/ 4-Wheel Drive) • all internal parts contained within the housing: differential housing/transaxle housing/ final drive housing • wheel hubs • axle shafts • universal joints
- hub locking rings & retainers • hub bearing support
 - hub bearings • constant velocity joints • driveshafts

FUEL

- fuel delivery pump • fuel sending unit • fuel injectors
- diesel injection pump • fuel lines & nozzles • fuel tank

HYBRID VEHICLE

- hybrid vehicle electric motor assembly
- electronic transmission/transaxle assembly
- electric traction-drive motor assembly

FILTERS, FLUIDS, LUBRICANTS & TAXES

Filters, fluids, lubricants and taxes required to complete a covered repair for any covered part listed above.

OPTIONAL PLAN UPGRADE

AIR CONDITIONING FOR POWERTRAIN

- condenser • compressor • compressor clutch
- evaporator • clutch coils • accumulator • dash control unit/ temperature control programmer receiver/dryer
- pressure cycling switch • blower motor high/low compressor cutoff switch • POA valve • clutch coils
- serpentine belt tensioner • orifice tube • power module
- pulleys and bearings • ducts and outlet hoses

SILVER COVERAGE

All parts listed under Powertrain, plus:

STEERING

- all internal lubricated parts within the steering gear, power steering pump and rack and pinion housing • steering column shaft
- steering linkage • control valve • power cylinder • pitman arm
 - power steering cooler lines • idler arm • tie rod ends
 - all internal lubricated parts • steering column shaft couplings

ELECTRICAL

- alternator voltage regulator • all electric motors & controllers
- alternator • delays and pumps • pole pieces • power door lock actuators • rear defrost • cruise control transducer • all relays and solenoids all switches including manually or mechanically-operated
- electrical switches • power door lock solenoids • starter motor • power window motors and window regulators • servo motors • ignition coils
- wiring harnesses • front and rear wiper motors • starter • starter solenoid • distributor including bushings, gear, housing and shaft

AIR CONDITIONING

- condenser • compressor • A/C receiver dryer • POA valve • orifice tube
- serpentine belt tensioner • compressor clutch and coils • pressure cycling switch • evaporator • accumulator • blower motor • pulleys and bearings • A/C ducts and outlet hoses • low pressure compressor cutoff switch • dash control unit/ temperature control • control programmer
- high pressure compressor cutoff switch

OPTIONAL PLAN UPGRADE

SEALS & GASKETS FOR POWERTRAIN OR SILVER

- Seals and gaskets within component groups
- Minor loss of fluid or seepage is considered normal and is not considered a mechanical breakdown.



833-357-2366 • 434-384-1150 • info@dkpadmin.com
4925 Boonsboro Road, Suite 238, Lynchburg, VA 24503

DKPADMIN.COM